

11964	Incident
11966	Incident
11968	Service
11970	ffičdliš?
11971	Service
11971	ffičdlišf
11974	Incident
11974	Service
11976	hncwesE
11976	Incident
11980	Incident
11982	Incident
11987	Service
11987	ffičdliš?
11998	Incident
11999	Incident
12000	Incident
12005	Incident
12006	Incident
12008	Incident
12009	Incident
12009	Incident
12011	Service
12011	hncdest
12013	Incident
12014	Incident
12014	Service
12015	hncwesE
12019	Incident
12019	Incident
12019	Incident
12019	Incident
12021	Service
12021	hncwesE
12024	Incident
12025	Incident
12028	Incident
12032	Incident
12032	Incident
12039	Incident
12039	Service
12040	hncwesf

12041	Service
12041	Sequeuet
12044	seque
12050	Š@qvčeť
12052	Rcquest
12054	Incident
12056	Incident
12056	Incident
12058	Incident
12060	Incident
12060	Incident
12061	Incident
12065	Incident
12066	Incident
12072	Service
12076	ftequeí
12077	Service
12078	ffičquesí
12079	Incident
12089	Incident
12101	Service
12107	seque
12113	ffičqueS!
12115	Incident
12116	Incident
12118	Incident
12121	Incident
12127	Incident
12127	Incident
12128	Incident
12131	Incident
12137	Service
12138	TflčqueSt
12141	Incident
12145	Incident
12148	Incident
12150	Incident
12150	Incident
12150	Incident
12156	Incident
12157	Incident
12159	Incident
12163	Incident
12163	Incident
12164	Service Request

12170	Incident
12172	Incident
12178	Incident
12189	Incident
12194	Incident
12201	Incident
12208	Incident
12215	Incident
12220	Incident
12228	Service
12248	servce
12257	Requeue
12259	Rfcdátff
12260	Incident
12260	Incident
12265	Incident
12266	Incident
12268	Incident
12275	Incident
12277	Incident
12281	Incident
12282	Incident
12283	Incident
12289	Service
12296	Redeí
12296	Incident
12308	Incident
12312	Incident
12315	Incident
12316	Incident
12317	Incident
12317	Incident
12317	Incident
12318	Incident
12319	Incident
12319	Incident
12321	Service
12321	servce
12322	RedeT
12324	Service
12328	Wftk^fder
12328	Incident
12334	Incident
12334	Incident
12335	Incident

12336	Service
12336	Rcdest
12342	Incident
12343	Incident
12343	Incident
12343	Incident
12344	Incident
12344	Incident
12345	Incident
12345	Incident
12347	Incident
12347	Incident
12347	Incident
12348	Incident
12351	Incident
12361	Incident
12363	Incident
12363	Incident
12376	Incident
12377	Incident
12378	Incident
12381	Incident
12382	Service
12389	
12390	Incident
12390	Service
12390	
12396	Incident
12396	Incident
12401	Incident
12403	Incident
12405	Incident
12406	Incident
12411	Incident
12413	Incident
12416	Incident
12417	Incident
12417	Incident
12417	Service
12418	
12418	Incident
12435	Incident
12436	Incident
12437	Work Order
12437	Problem

12441	Incident
12442	Incident
12447	Incident
12451	Incident
12453	Incident
12456	Incident
12457	Incident
12458	Service
12463	servce
12473	
12480	nqueí
12483	Incident
12483	Service
12484	RedeT
12488	Service
12488	Requeue
12491	Redeí
12491	Incident
12494	Incident
12495	Incident
12495	Incident
12495	Incident
12496	Incident
12502	Incident
12503	Incident
12503	Incident
12510	Incident
12515	Incident
12519	Incident
12519	Incident
12521	Incident
12523	Service
12527	Redeí
12528	Incident
12529	Incident
12529	Incident
12531	Incident
12531	Incident
12532	Incident
12533	Incident
12533	Incident
12535	Service
12536	Reder
12547	Service
12548	

12551	Incident
12554	Incident
12555	Incident
12556	Service
12559	Rcdest
12560	Incident
12560	Incident
12567	Incident
12578	Service
12584	Rcdes
12584	Incident
12585	Incident
12585	Incident
12590	Incident
12593	Incident
12595	Incident
12606	Service
12608	Requeue
12615	Rcdest
12615	Incident
12618	Service
12618	RcdIS?
12618	Incident
12619	Incident
12620	Incident
12624	Incident
12625	Incident
12626	Incident
12626	Incident
12630	Incident
12639	Incident
12639	Incident
12651	Incident
12652	Incident
12659	Service
12659	Rcdest
12660	Incident
12662	Incident
12662	Service
12663	gšFvuee^
12668	RSdĩñT
12669	Incident
12670	Incident
12672	Incident
12672	Incident

12674	Incident
12675	Incident
12676	Incident
12682	Incident
12682	Incident
12683	Incident
12691	Incident
12695	Incident
12695	Incident
12702	Service
12710	Rcdest
12712	Incident
12712	Incident
12713	Incident
12715	Incident
12715	Incident
12718	Incident
12718	Incident
12718	Incident
12719	Incident
12724	Incident
12725	Service
12728	Rcdest
12728	Service
12732	Rcdest
12734	Work Order
12735	Incident
12735	Incident
12739	Incident
12748	Incident
12749	Incident
12749	Service
12763	Rcdest
12763	Incident
12765	Incident
12771	Incident
12774	Service
12777	Rcdest
12785	Incident
12786	Problem
12792	Incident
12793	Service
12794	Rcdesf
12799	Incident
12800	Incident

12800	Incident
12807	Incident
12818	Incident
12818	Incident
12822	Service
12830	Rcdest
12830	Incident
12833	Incident
12837	Incident
12838	Incident
12838	Incident
12839	Incident
12843	Incident
12853	Incident
12853	Incident
12859	Incident
12877	Incident
12878	Service
12880	Rcdest
12882	Incident
12884	Incident
12885	Incident
12886	Incident
12887	Incident
12890	Incident
12895	Incident
12900	Incident
12900	Incident
12914	Incident
12925	Problem
12928	Incident
12935	Incident
12936	Incident
12936	Incident
12936	Incident
12937	Incident
12937	Incident
12943	Incident
12951	Incident
12951	Incident
12957	Incident
12958	Incident
12967	Incident
12971	Incident
12972	Incident

12972	Service
12972	RePVče*
12974	ffičd'gš?
12974	Incident
12976	Incident
12985	Incident
12987	Incident
12988	Incident
12988	Incident
12988	Incident
12988	Service
12988	sequeue
12989	aefwee
12991	RšFvúee^
12999	ffičdeí
13009	Incident
13027	Incident
13027	Incident
13029	Incident
13035	Incident
13041	Incident
13042	Incident
13050	Incident
13051	Incident
13055	Incident
13055	Incident
13058	Incident
13066	Incident
13066	Incident
13067	Incident
13069	Service
13180	ffičdeí
13181	Incident
13181	Incident
13193	Incident
13194	Incident
13204	Incident
13207	Incident
13222	Incident
13230	Incident
13230	Incident
13231	Incident
13232	Incident
13233	Incident
13233	Incident

13236	Service
13238	Rcdest
13241	Service
13258	fficquešt
13261	Incident
13264	Incident
13265	Incident
13266	Incident
13268	Service
13271	Rcdest
13276	Incident

Ticket Name

tv-os-rt-ce2-NNM-NNM-down-Node
mt-os-rt-ce1-NNM-NNM-down-Node
Profylaxia (recurrent)
Výpadok. el. en. OS Nové Zámky 7.4.2016 10-12h
Stahovanie OS RS
mi-os-sw-core1-Hardware-SNMPTra ps-cisco-envmon
rs-os-sw-core1-Hardware-SNMPTra ps-cisco-envmon
Nastavenie opraveni
nm-os-rt-ce2-NNM-NNM-down-Node
se-os-rt-ce2-NNM-NNM-down-Node
rs-os-sw-acc2-NNM-NNM-down-Node
nz-os-sw-core1-NNM-NNM-down-Node
Technické požiadavky k videozariadeniu
bb-ks-sw-acc1-NNM-NNM-down-Node
ba-ks-sw-core1-NNM-NNM-down-Node
lc-os-rt-ce1-Network-SNMPTra ps-cisco-bgp4
pp-os-rt-ce2-NNM-NNM-down-Node
Problem na switchi SVOLDACC1K1
KSZA - problem s pristupom do lan
mssr-NNM-NNM-down-Segment
ma-os-rt-ce2-NNM-NNM-down-Node
Vypadok Switchu
Osadenie prepínača _OS BA V
mt-os-rt-ce1-NNM-NNM-down-Node
Vypadok IP telefonov
rs-os-rt-ce1-NNM-NNM-down-Node
Presmerovanie tel. ústredne
ke-ks-sw-acc9-NNM-NNM-down-Node
nm-os-rt-ce1-Network-SNMPTraps-cisco-bgp4
pn-os-rt-ce2-NNM-NNM-down-Node
pd-os-sw-acc2-NNM-NNM-down-Node
ds-os-rt-ce1-Network-SNMPTraps-cisco-bgp4
IP telefonia - request
ke-ks-rt-ce1-NNM-NNM-down-Node
rs-os-rt-ce1-NNM-NNM-down-Node
Prístupné porty na IP telefón Námestie slobody
pn-os-rt-ce2-NNM-NNM-down-Node
ga-os-sw-core1-Hardware-SNMPTra ps-cisco-envmon
ga-os-sw-core1-Hardware-SNMPTra ps-cisco-envmon
bj-os-sw-core1-Hardware-SNMPTra ps-cisco-envmon
OSNR a KSNR - optický kábel
se-os-sw-core1-Hardware-SNMPTraps-cisco-envmon

Konfiguracia portu_otazka
Cisco Unified CM Administration_hlaska
Manual ku konfigurácii videozariadenia
Konfiguracia videozariadenia
Nedovolatelnost OS TN a sud v Slovinsku
Výpadok zaloznych liniek
mt-os-rt-ce1-NNM-NNM-down-Node
nr-ksos-rt-ce2-NNM-NNM-down-Node
ba4-os-rt-ce1-Network-SNMPTra ps-cisco-bgp4
problem s komunikaciou z proxy cez Slovanet do Int
vt-os-sw-core1-NNM-NNM-down-Node
za-ks-sw-core1-NNM-NNM-down-Node
po-ks-rt-cel-NNM-NNM-down-Node
se-os-sw-core1-Hardware-SNMPTraps-cisco-envmon
KS BA_analogova linka_FXS karta
sn-os-rt-ce2-NNM-NNM-down-Node
Preloženie videokonferencie OS Rimavská Sobota
ba3-os-sw-core1-NNM-NNM-down-Node
rv-os-rt-ce2-NNM-NNM-down-Node
no-os-rt-ce1-Network-SNMPTraps-cisco-bgp4
GBIC na pripojenie PoE switchu
Povolenie PoE portov
Fax_Namestovo
sk-os-rt-cel-NNM-NNM-down-Node
pn-os-sw-core1-NNM-NNM-down-Node
pn-os-sw-accl-NNM-NNM-down-Node
pd-os-sw-core1-NNM-NNM-down-Node
pe-os-rt-ce1-Network-SNMPTraps-cisco-bgp4
pe-os-rt-cel-NNM-NNM-down-Node
mi-os-rt-cel-NNM-NNM-down-Node
nr-ksos-sw-srvl-Hardware-SNMPTraps-cisco-envmon
Alarm_OS KE I
IPT nezvoni pri prichadzajucom hovore
rs-os-rt-cel-NNM-NNM-down-Node
ba4-os-sw-core1-NNM-NNM-down-Node
sn-os-sw-core1-NNM-NNM-down-Node
lc-os-rt-cel-Network-SNMPTra ps-cisco-bgp4
zvjs-zeliezovce-vv-rt-ce1-Network-SNMPTraps-cisco-bgp4
tv-os-sw-core1-Hardware-SNMPTra ps-cisco-envmon
ba4-os-sw-core1-NNM-NNM-down-Node
Fax_OS KE II
rk-os-rt-cel-Network-SNMPTra ps-cisco-bgp4 no-os-rt-ce1-
Network-SNMPTraps-cisco-bgp4 no-os-rt-ce2-NNM-NNM-down-
Node Reklamacia CISCO ATA190

zvjs-il-mierove-namestie-vv-rt-ce1-NNM-NNM-down-Node

Videokonferencne zariadenie_STS Pezinok
zh-os-rt-ce2-NNM-NNM-down-Node
ba3-os-rt-ce1-Network-SNMPTra ps-cisco-bgp4
za-os-rt-ce1-Network-SNMPTra ps-cisco-bgp4
zvjs-dubnica-nad-vahom-dukelska-vv-rt-ce1-NNM-NNM-down-Node
Výpadok elek.energie na OSTO
bb-os-sw-core1-Hardware-SNMPTraps-cisco-envmon
Nefungujúce volania mimo rezort spravodlivosti
Redundancia serverov
Videokonferencia s Madarskym sudom
Prestahovanie videokonf. systemu
tn-os-sw-core1-NNM-NNM-down-Node
pk-ja-rt-ce1-Network-SNMPTra ps-cisco-bgp4
pk-ss-rt-ce1-Network-SNMPTraps-cisco-bgp4
bj-os-rt-ce2-NNM-NNM-down-Node
dk-os-sw-core1-NNM-NNM-down-Node
si-os-rt-ce1-NNM-NNM-down-Node
Videozariadenie_ Justicna akademia _Omsenie
tn-os-rt-ce1-Network-SNMPTra ps-cisco-bgp4
ba5-os-sw-core1-NNM-NNM-down-Node
pk-ss-sw-acc1-NNM-NNM-down-Node
no-os-rt-ce2-NNM-NNM-down-Node
Instalacia videozariadenia_MSSR
za-ks-sw-core1-NNM-NNM-down-Node
mi-os-rt-ce2-NNM-NNM-down-Node
zvjs-ba-chorvatska-vv-rt-ce1-NNM-NNM-down-Node
pd-os-sw-acc2-NNM-NNM-down-Node
po-ks-rt-ce1-Network-SNMPTra ps-cisco-bgp4
br-os-sw-core1-NNM-NNM-down-Node
sk-os-rt-ce1-Network-SNMPTraps-cisco-bgp4
ace2-NNM-NNM-down-Node
ace1-NNM-NNM-down-Node
bj-os-sw-core1-NNM-NNM-down-Node
pn-os-sw-core1-NNM-NNM-down-Node
Neprechadza obraz pri videokonferencii
Videokonferencie cez virtualne miestnosti
Videokonferencie cez virtualne miestnosti
ke-dc-rt-ce1-Network-SNMPTraps-cisco-bgp4
Zapojenie video EX90 - MSSR Omsenie
Update firmware na serveroch a endpointoch
rv-os-rt-ce2-NNM-NNM-down-Node
za-os-rt-ce2-NNM-NNM-down-Node
bj-os-rt-ce1-NNM-NNM-down-Node

zvjs-il-mierove-namestie-vv-sw-core1-NNM-NNM-down-Node

Vytvorenie uctu do TMS

CPP neregistrované videozariadenia

rk-os-rt-cel-Network-SNMPTra ps-cisco-bgp4

zvjs-zeliezovce-vv-rt-ce1-NNM-NNM-down-Node

zvjs-zeliezovce-vv-rt-ce1-NNM-NNM-down-Node

dk-os-sw-core1-NNM-NNM-down-Node

zvjs-zeliezovce-vv-sw-core1-NNM-NNM-down-Node

mt-os-sw-core1-NNM-NNM-down-Node

zvjs-ke-saca-budovatelska-vv-sw-core1-Hardwa re-SNMPTraps-cisco-

po^{vm}?-í't'ce2-NNM-NNM-down-Node

Nefunkčný tel. korporatny adresar

Oregistrovane videokonf. zariadenie

ace1-NNM-NNM-down-Node

Videokonferencne spojenie_lokalita Obvodni sud Pra

tv-os-sw-acc4-NNM-NNM-down-Node

nr-ksos-sw-acc1-NNM-NNM-down-Node

zvjs-zeliezovce-vv-sw-core1-NNM-NNM-down-Node

zvjs-zeliezovce-vv-rt-ce1-NNM-NNM-down-Node

zvjs-le-namestie-stefana-kluberta-vv-rt-ce1-NNM-NNM-down-Node

mssr-NNM-NNM-down-Segment

kn-os-rt-ce2-NNM-NNM-down-Node

zvjs-le-namestie-stefana-kluberta-vv-sw-core1-NNM-NNM-down-Node

Profylaxia (recurrent)

no-os-rt-ce2-NNM-NNM-down-Node

pd-os-sw-core1-NNM-NNM-down-Node

Doplnenie MSSR_SLA report

pn-os-rt-ce1-NNM-NNM-down-Node

mssr-NNM-NNM-down-Segment

zvjs-leopoldov-gucmanova-vv-sw-core1-NNM-NNM-down-Node

no-os-rt-ce1-NNM-NNM-down-Node

tt-ks-sw-core1-NNM-NNM-down-Node

nm-os-rt-ce1-NNM-NNM-down-Node

no-os-sw-core1-NNM-NNM-down-Node

Videokonferencny hovor s CR

Nefunkčnosť korp. tel. zoznamu

zvjs-nr-dntorinska-vv-rt-ce1-NNM-NNM-down-Node

bn-os-rt-ce2-NNM-NNM-down-Node

bn-os-rt-ce2-NNM-NNM-down-Node

Demontaz video konferencie

po-os-sw-core1-NNM-NNM-down-Node

bj-os-sw-core1-NNM-NNM-down-Node

rv-os-rt-ce2-NNM-NNM-down-Node

po-os-sw-acc6-NNM-NNM-down-Node

Analzya rizik vypadku vetvy napajania v DC BA a KE

Pricina poslednych výpadkov korp. zoznamu

ds-os-rt-ce1-Network-SNMPTraps-cisco-bgp4

ca-os-rt-cel-NNM-NNM-down-Node
nm-os-rt-cel-NNM-NNM-down-Node
si-os-rt-cel-NNM-NNM-down-Node
ba-ks-sw-core1-NNM-NNM-down-Node
ba-ks-sw-acc10-NNM-NNM-down-Node
pk-ss-sw-core1-NNM-NNM-down-Node
KOnfiguracia portu na videokonferencne zariadenie
KOntrola portu
Videokonferencia rezervacia
zv-os-rt-ce2-NNM-NNM-down-Node
no-os-rt-cel-NNM-NNM-down-Node
Pridelenie IP adresy
zvjs-zeliezovce-vv-rt-ce1-NNM-NNM-down-Node
Nastavenie voľného portu na IP telefón
Nastavenie prevodníka ATA190
rv-os-rt-ce2-NNM-NNM-down-Node
zvjs-zeliezovce-vv-sw-core1-NNM-NNM-down-Node
zvjs-zeliezovce-vv-rt-ce1-NNM-NNM-down-Node
zvjs-zeliezovce-vv-sw-core1-NNM-NNM-down-Node
zvjs-zeliezovce-vv-sw-core1-NNM-NNM-down-Node
kn-os-rt-ce2-NNM-NNM-down-Node
zvjs-dubnica-nad-vahom-dukelska-vv-sw-core1-NNM-NNM-down-Node
ca-os-rt-ce1-Network-SNMPTra ps-cisco-bgp4
za-os-rt-ce1-Network-SNMPTra ps-cisco-bgp4
za-ks-rt-ce1-Network-SNMPTraps-cisco-bgp4
ga-os-rt-ce1-NNM-NNM-down-Node
no-os-sw-core1-NNM-NNM-down-Node
nm-os-rt-ce2-NNM-NNM-down-Node
no-os-rt-ce2-NNM-NNM-down-Node
to-os-rt-ce1-NNM-NNM-down-Node
Zostavenie spojenia medzi SR a CR sudom
pe-os-rt-ce1-NNM-NNM-down-Node
pk-ja-sw-core1-NNM-NNM-down-Node
no-os-rt-ce1-NNM-NNM-down-Node
pn-os-sw-core1-NNM-NNM-down-Node
tt-os-sw-core1-NNM-NNM-down-Node
ma-os-rt-ce1-NNM-NNM-down-Node
ds-os-sw-core1-NNM-NNM-down-Node
no-os-rt-ce1-NNM-NNM-down-Node
zvjs-ba-sagatova-gr-sw-core1-NNM-NNM-down-Node
Zmena - Mail adresa
zvjs-ke-saca-budovatelska-vv-rt-ce1-NNM-NNM-down-Node
Export dat z CUCM

nm-os-rt-ce2-NNM-NNM-down-Node

dk-os-sw-core1-NNM-NNM-down-Node

nm-os-rt-ce2-Network-SNMPTraps-cisco-bgp4

lm-os-sw-core1-NNM-NNM-down-Node

Kontrola konfigurácie telefónu a switchportu

pn-os-rt-ce1-NNM-NNM-down-Node

tt-ks-rt-ce1-NNM-NNM-down-Node

Po krátkodobom výpadku nepinga server ani userov

zvjs-il-mierove-namestie-vv-rt-ce1-NNM-NNM-down-Node

Blokovanie hovorov z konkrétneho čísla

pk-ja-sw-core1-NNM-NNM-down-Node

za-ks-rt-ce2-NNM-NNM-down-Node

zvjs-za-hlboka-cesta-vv-sw-core1-NNM-NNM-down-Node

za-os-rt-ce2-NNM-NNM-down-Node

ke-ks-rt-ce2-NNM-NNM-down-Node

dk-os-rt-ce2-NNM-NNM-down-Node

zvjs-zeliezovce-vv-rt-ce1-NNM-NNM-down-Node

RESS/IS-Video

Kontrola/nakonfigurovanie portu pk-ja-rt-ce2-NNM-NNM-down-Node pk-ss-

rt-ce2-NNM-NNM-down-Node Preverenie konfigurácie routra Odhlasovanie

užívateľov zo siete

zvjs-ke-saca-budovatelska-vv-rt-ce1-NNM-NNM-down-Node

vk-os-rt-ce2-NNM-NNM-down-Node

bj-os-sw-core1-NNM-NNM-down-Node

zvjs-il-mierove-namestie-vv-rt-ce1-NNM-NNM-down-Node

ma-os-rt-ce1-NNM-NNM-down-Node

pk-ss-sw-acc1-NNM-NNM-down-Node

pk-ja-sw-core1-NNM-NNM-down-Node

dk-os-rt-ce2-NNM-NNM-down-Node

bb-os-rt-ce1-Network-SNMPTraps-cisco-bgp4

zvjs-il-mierove-namestie-vv-rt-ce1-NNM-NNM-down-Node

ke-ks-sw-core1-NNM-NNM-down-Node

ace2-NNM-NNM-down-Node

Videokonferencia 13.9.2016 s Madarskom.

zvjs-dubnica-nad-vahom-dukelska-vv-sw-core1-NNM-NNM-down-Node

zvjs-dubnica-nad-vahom-dukelska-vv-rt-ce1-NNM-NNM-down-Node

rs-os-sw-core1-NNM-NNM-down-Node

Dokonfigurovanie EX 60

Pristupove hesla do nahlasovacieho systemu

pk-ss-sw-core1-NNM-NNM-down-Node

pk-ss-sw-core1-NNM-NNM-down-Node

Neprechádzajú maily, problém s Exchange serverom

Outlook_rezervacia videokonferencie

zvjs-ba-chorvatska-vv-rt-ce1-NNM-NNM-down-Node

tt-ks-sw-core1-NNM-NNM-down-Node

bn-os-rt-cel-NNM-NNM-down-Node

ga-os-rt-ce1-Network-SNMPTraps-cisco-bgp4

tt-os-sw-core1-NNM-NNM-down-Node

zvjs-le-namestie-stefana-kluberta-vv-sw-core1-NNM-NNM-down-Node

zvjs-le-namestie-stefana-kluberta-vv-rt-cel-NNM-NNM-down-Node

he-os-sw-accl-NNM-NNM-down-Node

Nefunkcne pripojenie na ovladaci panel

vt-os-rt-cel-NNM-NNM-down-Node

Videokonferencny hovor_ Holansko

ga-os-rt-cel-NNM-NNM-down-Node

ba-ov-rt-cel-NNM-NNM-down-Node

Sietovy problém Okresný sud Galanta

mi-os-sw-acc2-NNM-NNM-down-Node

pn-os-sw-accl-NNM-NNM-down-Node

pn-os-sw-core1-NNM-NNM-down-Node

ra-os-sw-core1-NNM-NNM-down-Node

pn-os-sw-core1-NNM-NNM-down-Node

ra-os-sw-accl-NNM-NNM-down-Node

ba4-os-rt-ce1-Network-SNMPTra ps-cisco-bgp4

nz-os-rt-cel-NNM-NNM-down-Node

Kontrola stavu a funkčnosti na lokalite BA-OV

Výpadok videokonferencneho systemu_vyjadrenie

vytvorenie konta_TMS

ga-os-rt-ce2-NNM-NNM-down-Node

Zapojenie tel. klapky do výťahu na OS TT

pk-ss-sw-core1-NNM-NNM-down-Node

pk-ja-sw-core1-NNM-NNM-down-Node

Presmerovanie hovorov

pd-os-sw-core1-NNM-NNM-down-Node

ra-os-rt-cel-NNM-NNM-down-Node

Nastavenie VLAN pre daný port

ke-ks-sw-core1-NNM-NNM-down-Node

ke-dc-fw-edge-NNM-NNM-down-Node

za-os-rt-cel-NNM-NNM-down-Node

mt-os-rt-cel-NNM-NNM-down-Node

Profylaxia (recurrent)

Výpadok IP telefónov OS Žilina-OR mssr-NNM-NNM-down-Segment Analyza

vypadku MSSR lokalit BA Krajsky Sud - kratkodoby vypadok konektivity

Kontrola VLAN na switchi na Okresnom sude Svidnik Nefunkčná sieť počas

video prenosu dna 5.10.2016 tt-ks-rt-cel-Network-SNMPTra ps-cisco-bgp4 sl-

os-rt-ce2-Network-SNMPTra ps-cisco-bgp4

sl-os-rt-cel-Network-SNMPTra ps-cisco-bgp4

kk-os-rt-ce2-NNM-NNM-down-Node
fw-NNM-NNM-down-Node
ba-zup-sw-core1-NNM-NNM-down-Node
Volny slot pre telefón - Okresný súd Námestovo
bn-os-rt-ce2-NNM-NNM-down-Node
se-os-rt-ce2-NNM-NNM-down-Node
tt-ks-sw-core1-NNM-NNM-down-Node
tt-os-sw-core1-Hardware-SNMPTraps-cisco-envmon
ke1-osor-rt-ce2-NNM-NNM-down-Node
zvjs-ke--florianska-vv-rt-ce1-NNM-NNM-down-Node
no-os-rt-ce1-Network-SNMPTraps-cisco-bgp4
zvjs-ba-chorvatska-vv-rt-ce1-NNM-NNM-down-Node
zvjs-rk-doncova-vv-rt-ce1-NNM-NNM-down-Node
rk-os-rt-ce2-NNM-NNM-down-Node
kn-os-rt-ce2-NNM-NNM-down-Node
Konferenčný hovor
Konfiguracia Audio konferencie
pn-os-sw-core1-NNM-NNM-down-Node
OSTT - vypadok
zv-os-rt-ce1-NNM-NNM-down-Node
Problem s vytvorenou videokonferenciou cez TMS
Nefunkcny mikrofón na videokonf. zariadení
ba-dc-rt-ce2-Network-SNMPTraps-cisco-bgp4
nr-ksos-sw-acc1-NNM-NNM-down-Node
ke-ks-sw-core1-NNM-NNM-down-Node
ke-dc-tcs-cimc-Hardware-SNMPTra ps-FaultActive
ba-dc-tcs-cimc-Hardware-SNMPTra ps-FaultActive
vt-os-sw-core1-NNM-NNM-down-Node
Update CIMC na UCS serveroch
se-os-rt-ce2-NNM-NNM-down-Node
mi-os-rt-ce2-NNM-NNM-down-Node
pk-ja-sw-acc1-NNM-NNM-down-Node
pk-ss-rt-ce2-Network-SNMPTraps-cisco-bgp4
pk-ja-rt-ce1-Network-SNMPTra ps-cisco-bgp4
kn-os-rt-ce2-NNM-NNM-down-Node
ca-os-rt-ce1-NNM-NNM-down-Node
ba-dc-esxi-acs2-Hardware-SNMPTraps-VMware
rk-os-rt-ce2-Network-SNMPTra ps-cisco-bgp4
rk-os-rt-ce2-NNM-NNM-down-Node
bb-os-sw-core1-NNM-NNM-down-Node
zvjs-bb-komenskeho-vv-rt-ce1-NNM-NNM-down-Node
zvjs-nr-cintorinska-vv-sw-core1-NNM-NNM-down-Node
bb-ks-rt-ce2-NNM-NNM-down-Node

ba2-os-sw-acc2-NNM-NNM-down-Node

RESS/IS-Video

vytvorenie VPN profilu pre pristup na xxxxxx Videokonferencne zariadenie OSBA1 ba-dc-esxi-acs2-Hardware-SNMPTraps-VMware tv-os-rt-ce2-NNM-NNM-down-Node Nefunguju prichodzie hovory.

zvjs-bb-kralova-sladkovicova-vv-sw-corel-NNM-NNM-down-Node

mt-os-sw-corel-NNM-NNM-down-Node

zh-os-rt-cel-NNM-NNM-down-Node

zvjs-tn-sudna-uvtos-sw-corel-NNM-NNM-down-Node

Zrusenie pristupov p. xxxxxxxxxxxxxxxxxx

Vytvorenie pristupov do TMS

Cisla virtuálnych videokonferencnych miestnosti

IP telefon historia hovorov

za-ks-rt-ce1-Network-SNMPTraps-cisco-bgp4

bj-os-rt-ce2-NNM-NNM-down-Node

nr-ksos-sw-corel-NNM-NNM-down-Node

Nefunkcne planovanie v TMS

zvjs-ba-sagatova-gr-rt-cel-NNM-NNM-down-Node

zvjs-ba-sagatova-gr-rt-cel-NNM-NNM-down-Node

za-ks-sw-corel-NNM-NNM-down-Node

Nefunkcne faxove linky

ke-dc-esxi-acsl-Hardware-SNMPTraps-VMware

pn-os-rt-ce2-NNM-NNM-down-Node

zvjs-zeliezovce-vv-rt-ce1-Network-SNMPTraps-cisco-bgp4

mssr-NNM-NNM-down-Segment

Vypadok konektivity - KS Bratislava

Nefunkcny mikrofón

zvjs-sucany-vv-rt-cel-NNM-NNM-down-Node

mt-os-rt-ce2-NNM-NNM-down-Node

Cisla videokonferencnych miestnosti

tv-os-rt-ce2-NNM-NNM-down-Node

ke-dc-esxi-acs2-Hardware-SNMPTraps-VMware

ba-dc-tcs-cimc-Hardware-SNMPTraps-FaultActive

ra-os-rt-cel-NNM-NNM-down-Node

to-os-sw-corel-NNM-NNM-down-Node

zvjs-bb-kralova-sladkovicova-vv-sw-corel-NNM-NNM-down-Node

ZVJS-Nefunguje zostavenie telekonferencie.

pk-ss-rt-ce1-Network-SNMPTraps-cisco-bgp4

pd-os-sw-acc2-NNM-NNM-down-Node

ba-ks-rt-ce2-NNM-NNM-down-Node

ke-dc-rt-ce1-Network-SNMPTraps-cisco-bgp4

ca-os-sw-acc2-NNM-NNM-down-Node

zvjs-rk-doncova-vv-rt-cel-NNM-NNM-down-Node

ba-dc-esxi-ipt-Hardware-SNMPTraps-VMware

Postup otestovania funkčnosti záložných liniek

zvjs-rk-doncova-vv-sw-core1-NNM-NNM-down-Node

Rozšírenie siete (masky siete) na OSZA

za-ks-rt-ce2-NNM-NNM-down-Node

tt-ks-sw-core1-NNM-NNM-down-Node

za-os-sw-acc1-NNM-NNM-down-Node

zvjs-ba-sagatova-gr-sw-core1-NNM-NNM-down-Node

zvjs-ba-sagatova-gr-rt-ce1-Network-SNMPTraps-dsco-bgp4

zapojenie ATA prevodnikov

rs-os-rt-ce1-NNM-NNM-down-Node

vt-os-rt-ce1-NNM-NNM-down-Node